

Siya User Guide



3-way adjustable arm rests

Adjusts forward/back, side-to-side, up and down. Press button to adjust arms.



height adjustable lumbar

Place hands on left and right sides to glide up or down.



seat depth

Lift lever and hold, slide seat forward or back, and release lever to lock.



width adjustable arms

Push lever down and move arms in or out, pull lever back up to lock.



back tension

Controls resistance to body weight. Turn knob forward for more resistance and backward for less.



seat height adjustment

To raise the chair, lift your body weight and pull lever up. To lower the chair, stay seated and pull lever up.



back lock

Multi-position locking mechanism. Rotate knob to lock or unlock.